



PARTS KEY NO.	DESCRIPTION	PARTS CODE	QUANTITY
1	Screw - Belt Cover , M4 X 12	ALL.FG.SCREW015	4
2	Screw - Blade , M6 X 10	ALL.FG.SCREW012	4
3	Brush - Cover	ALL.FG.BRUSH006	2
4	Washer - Step	ALL.FG.WASH024	1
5	Nut - Nyloc M6	ALL.FG.NUT006	1
6	Brush - Carbon 240V 900W		2
7	Brush - Carbon 110V 900W	ALL.FG.BRUSH004	2
8	Clip - Internal	ALL.FG.CLIP001	2
9	Pin	ALL.FG.PIN002	2
10	Pulley - Tension including Bearing - 696	ALL.FG.TENSION001	1
11	Pulley - Power	ALL.FG.PULLEY005	1
12	Pulley - Drive	ALL.FG.PULLEY004	1
13	Belt	ALL.FG.BELT002	1
14	Bush	ALL.FG.BUSH001	4
15	Guard	ALL.FG.GUARD002	1
16	Handle - Top	ALL.FG.HANDLE001	1
17	Conrod Assembly	ALL.FG.CONROD001	1
18	Spring Assembly	ALL.FG.SPRINGASS001	1
19	Conrod & Cam	ALL.FG.CONROD003	1
20	Cover - Belt	ALL.FG.COVER001	1
21	Housing - Left Hand	ALL.FG.HOUSELH	1
22	Housing - Right Hand	ALL.FG.HOUSERH	1
23	Motor - 240V 900W	ALL.FG.MOTOR003	1
24	Motor - 110V 900W	ALL.FG.MOTOR004	1
25	Electrical Plug (Regional)		1
26	Boot - Dust Extraction Funnel	ALL.FG.BOOT001	1
27	Bracket - Dust Extraction Fitting	ALL.FG.BRACKET003	1
28	Brush - Holder 900W	ALL.FG.BRUSH005	2
29	Switch - 240V 900W		1
30	Switch - 110V 900W	ALL.FG.SWITCH003	1
31	Switch Dust inhibiting - 110V 900W	ALL.FG.DUST003	1
32	Seal - O Ring	ALL.FG.SEAL001	1
33	Bearing - Camshaft 6001	ALL.FG.BEARING002	1
34	Bearing - Right Hand Crown 629	ALL.FG.BEARING004	1
35	Crown Shaft Assembly	ALL.FG.CROWN	1
36	Bearing - Camshaft 6001	ALL.FG.BEARING002	1
37	Bearing - Left hand Crown 6201	ALL.FG.BEARING006	1
38	Screw - Housing M5 X 25	ALL.FG.SCREW011	5
39	Handles - Rear	ALL.FG.HANDLE002	1
40	Screw - Outer Field Housing 4 X 25	ALL.FG.SCREW014	4
41	Pin - Dowell M3 X 16	ALL.FG.PIN001	1
42	Bolt - M6 X 20	ALL.FG.BOLT004	1
43	Cover - Vent	ALL.FG.COVER002	1
44	General Purpose Blades	BLA.FG.1000	1
	Key - Torque 16 Nm	ALL.FG.KEY004	1
	Case	ALL.FG.CASE002	1

AS160
 PRODUCTION GENERAL ASSEMBLY
 REV: AS160280808